

FITTING INSTRUCTIONS

TO BE FITTED BY A QUALIFIED TECHNICIAN

Threaded Brake Lever Guard **Part No. BLG-M8-S20-B5-R6-A160**

Threaded Clutch Lever Guard **Part No. CLG-M8-S20-B5-R6-A160**

Please note: fits 2025-2026 models only.

M8 THREADED BRAKE LEVER GUARD, 20mm SPACER WITH 6MM RECESS, 160mm MOULD PART NO. BLG-M8-S20-B5-R6-A160

- 1 Remove existing bar end - See pic Fig. 2 before assembly - and replace with supplied assembly as in Fig. 1 below.
- 2 Tighten bolt until the lever protector is tight and does not move up or down under normal pressure.
Torque the M8 bolt to 20Nm.
- 3 Do not ride if you are unsure if it is tight enough and always get a trained technician to confirm.

Please note: We recommend to use a medium thread lock (not supplied) for correct operation.




Fig. 1: ASSEMBLY

Fig. 2 BEFORE ASSEMBLY:



M8 THREADED CLUTCH LEVER GUARD, 20mm SPACER WITH 6MM RECESS, 160mm MOULD PART NO. CLG-M8-S20-B5-R6-A160

- 1 Remove existing bar end and replace with supplied assembly as in Fig. 1 below.
- 2 Tighten bolt until the lever protector is tight and does not move up or down under normal pressure.
Torque the M8 bolt to 20Nm.
- 3 Do not ride if you are unsure if it is tight enough and always get a trained technician to confirm.

Please note: We recommend to use a medium thread lock (not supplied) for correct operation.



Fig. 1: ASSEMBLY



FITTING INSTRUCTIONS

TO BE FITTED BY A QUALIFIED TECHNICIAN

UNIVERSAL BRAKE LEVER GUARD, **A160 MOULDED REPLACEMENT PART ONLY** **PART NO. BLG-A160**

This is to be used with the GBRacing bar end and insert

- 1 Remove full assembly from bars.
- 2 Remove bolt from assembly.
- 3 Replace lever protector.
- 4 Re-install bolt.
- 5 Re-fit the full assembly back into bar.
- 6 Tighten bolt until the lever protector is tight and does not move up or down under normal pressure.
- 7 Do not ride if you are unsure if it is tight enough and always get a trained technician to confirm.

Please note: We recommend to use a medium thread lock (not supplied) for correct operation.



UNIVERSAL CLUTCH LEVER GUARD, **A160 MOULDED REPLACEMENT PART ONLY** **PART NO. CLG-A160**

This is to be used with the GBRacing bar end and insert

- 1 Remove full assembly from bars.
- 2 Remove bolt from assembly.
- 3 Replace lever protector.
- 4 Re-install bolt.
- 5 Re-fit the full assembly back into bar.
- 6 Tighten bolt until the lever protector is tight and does not move up or down under normal pressure.
- 7 Do not ride if you are unsure if it is tight enough and always get a trained technician to confirm.

Please note: We recommend to use a medium thread lock (not supplied) for correct operation.

