

FITTING INSTRUCTIONS

TO BE FITTED BY A QUALIFIED TECHNICIAN

Bullet Frame Slider Camera Mounts



In order to fit these camera mounts, you must already have purchased the correct official GBRacing Bullet Frame Slider for your motorcycle from GBRacing.eu or one of our approved dealers / importers.

These camera mounts are an *additional part to replace the CPM-3* standard moulded part that comes with all GBRacing Bullet Frame Sliders.

GoPro Camera Mount

PART NO. CPM-3-GP

- 1 Remove retaining bolt M6x10A2CSK from the existing CPM-3 then slide the puck (CPM-3) off.
- 2 Slide your new CPM-3-GP on to the bush then re-install the M6x10A2CSK



CPM-3-GP

Bolt M6X10A2CSK
Not included