

APRILIA TUONO V4R 2011 - 2012



FITTING INSTRUCTIONS. TO BE FITTED BY A QUALIFIED TECHNICIAN.

Left Hand Side Bullet Frame Slider - STREET

FS-V4R-2011-LHS-S

- (1) Remove upper engine mounting bolt, located through the fairing opening.
- (2) Assemble bolt through the aluminium bush into correct position.
- (3) Tighten to 40NM torque.
- (4) Slide bullet moulding onto aluminium bush.
- (5) Screw M6 bolt into front of bullet moulding hand tight.

Right Hand Side Bullet Frame Slider - STREET

FS-V4R-2011-RHS-S

- (1) Remove upper engine mounting bolt, located through the fairing opening.
- (2) Assemble bolt through the aluminium bush into correct position.
- (3) Tighten to 40NM torque.
- (4) Slide bullet moulding onto aluminium bush.
- (5) Screw M6 bolt into front of bullet moulding hand tight.



CPB-10-50-13

CPM-3



M10x60



CPB-10-50-13

CPM-3



M10x70