

## FITTING INSTRUCTIONS



690 Duke 2011-21 | 690 SMC 2019-21 | 690/R Enduro 2008-18

THIS SHEET INCLUDES FITTING INSTRUCTIONS FOR THE FOLLOWING PARTS:

Secondary Alternator Cover Part No. EC-690-2011-1-GBR / Secondary Clutch Cover Part No. EC-690-2011-2-GBR / Paddock Stand Bobbin Set Part No. BA12-10-1-5-GBR-SET /



## SECONDARY ALTERNATOR COVER PART NO. EC-690-2011-1-GBR

- Remove 4 existing bolts from the stock Alternator cover, shown as position Bolt 1, 2, 3 & 4.
- 2 Place the Secondary Alternator Cover over the stock cover.
- 3 Assemble 4 replacement bolts loosely in the correct position as shown.
- 4 Tighten bolts to a Torque of 12Nm as per Manufacturer's recommendations.
  DO NOT OVERTIGHTEN.





## SECONDARY CLUTCH COVER PART NO. EC-690-2011-2-GBR

- Remove 4 existing bolts from the stock Clutch cover, shown as position Bolt 1, 2, 3 & 4.
- 2 Place the Secondary Clutch Cover over the stock cover.
- 3 Assemble 4 replacement bolts loosely in the correct position as shown.
- 4 Tighten bolts to a Torque of 12Nm as per Manufacturer's recommendations.
  DO NOT OVERTIGHTEN.





## PADDOCK STAND / BOBBIN SET PART NO. BA12-10-1-5-GBR-SET

- 1 Assemble the M10 Stainless Steel bolt through the moulded bobbin and the Black Anodised Bush.
- 2 Tighten bolts to the swing arm boss, 8 N/m. DO NOT OVERTIGHTEN.







Engine Cover Set: EC-690-2011-SET-GBR FC-690-2011-1-GBR FC-690-2011-2-GBR

www.**GB**Racing.eu