

1290(R) SUPER DUKE 2014-2016 & 1290 Super Adventure R/S 2019-2023

FITTING INSTRUCTIONS CBRacing® Vorid Class Motorcycle Protection

## THIS SHEET INCLUDES FITTING INSTRUCTIONS FOR THE FOLLOWING PARTS:

Secondary Alternator Cover Part No. EC-RC8-2011-1-GBR / Secondary Clutch Cover Part No. EC-1290-2014-2-GBR

## SECONDARY ALTERNATOR COVER PART NO. EC-RC8-2011-1-GBR

- Remove side fairing. 1
- 2 Remove 3 existing bolts from the stock Alternator cover, shown as position Bolt 1,2 & 3.

TO BE FITTED BY A QUALIFIED TECHNICIAN

- 3 Place the Secondary Alternator Cover over the stock cover.
- 4 Assemble 3 replacement bolts loosely in the correct position as shown.
- 5 Tighten bolts to a Torque of 10Nm as per Manufacturer's recommendations. DO NOT OVERTIGHTEN.





Bolt 1

SPB-2

## SECONDARY CLUTCH COVER PART NO. EC-1290-2014-2-GBR

- 1 Remove 3 existing bolts from the stock Clutch cover, shown as position Bolt 1, 2 & 3.
- 2 Place the Secondary Clutch Cover over the stock cover.
- 3 Assemble 3 replacement bolts loosely in the correct position as shown.
- 4 Tighten bolts to a Torque of 10Nm as per Manufacturer's recommendations. DO NOT OVERTIGHTEN.





## www.GBRacing.eu

Engine Cover Set: EC-1290-2014-SET-GBR EC-RC8-2011-1-GBR, EC-1290-2014-2-GBR

DO NOT use these products unless you agree to our Terms & Conditions, as shown on our paperwork and website. If you do not agree, please return the product(s) to your dealer for a refund.