HOW TO REPLACE THE GBRacing® LOGO BLOCK





RECOMMENDED TOOLS:

- FLAT HEAD SCREWDRIVER
- TIGER SEAL (OR EQUIVALENT HEAT PROOF ADHESIVE)

ON REVERSE OF ENGINE COVER
PUSH THE LOGO BLOCK OUT
USING SCREWDRIVER

USING SCREWDRIVER, CHISEL OUT LOGO BLOCK AND GLUE

ONCE THE LOGO BLOCK AREA
IS CLEAR, APPLY TWO PEA SIZED
AMOUNTS OF TIGER SEAL

STICK NEW LOGO BLOCK IN PLACE AND LEAVE FOR 30 MINUTES TO SET









