


THIS SHEET INCLUDES FITTING INSTRUCTIONS FOR THE FOLLOWING PARTS:

Secondary Alternator Cover Part No. EC-CBR1000RR-2020-1-GBR / Secondary Clutch Cover Part No. EC-CBR1000RR-2020-2-GBR /  
Secondary Pulse Cover Part No. EC-CBR1000RR-2020-3-GBR



**SECONDARY ALTERNATOR COVER**  
**PART NO. EC-CBR1000RR-2020-1-GBR**

1. Remove original fairing panel.
2. Remove 4 existing bolts from the stock Alternator cover, shown as position Bolt 1, 2, 3 & 4.
3. Place the Secondary Alternator Cover over the stock cover.
4. Assemble 4 replacement bolts (M6X35HHF) loosely in the correct position as shown.
5. Tighten bolts to a Torque of 10Nm as per Manufacturer's recommendations. **DO NOT OVERTIGHTEN.**
6. Replace fairing.



Bolt 1  
M6X35HHF - 10Nm




Bolt 2  
M6X35HHF - 10Nm

Bolt 3  
M6X35HHF - 10Nm

Bolt 4  
M6X35HHF - 10Nm

**SECONDARY CLUTCH COVER**  
**PART NO. EC-CBR1000RR-2020-2-GBR**

1. Remove 3 existing bolts from the stock Clutch cover, shown as position Bolt 1, 2 & 3.
2. Place the Secondary Clutch Cover over the stock cover.
3. Assemble the 3 replacement bolts loosely in the correct position as shown.
4. Tighten bolts to a Torque of 10Nm as per Manufacturer's recommendations. **DO NOT OVERTIGHTEN.**



Bolt 3  
M6x40HHF - 10Nm



Bolt 1  
M6x40HHF - 10Nm


Bolt 2  
M6x55HHF - 10Nm

**SECONDARY PULSE COVER**  
**PART NO. EC-CBR1000RR-2020-3-GBR**

1. Remove 3 existing bolts from the stock Pulse cover, shown as position Bolt 1, 2 & 3.
3. Place the Secondary Pulse Cover over the OEM stock cover.
4. Assemble the 3 replacement bolts loosely in the correct position as shown.
5. Tighten bolts to a Torque of 10Nm as per Manufacturer's recommendations.



Bolt 3  
M6X35HHF - 10Nm



Bolt 1  
M6X35HHF - 10Nm

Bolt 2  
M6X35HHF - 10Nm

**SET PART No:** EC-CBR1000RR-2020-SET-GBR: EC-CBR1000RR-2020-1-GBR / EC-CBR1000RR-2020-2-GBR / EC-CBR1000RR-2020-3-GBR