

FITTING INSTRUCTIONS TO BE FITTED BY A QUALIFIED TECHNICIAN



THIS SHEET INCLUDES FITTING INSTRUCTIONS FOR THE FOLLOWING PARTS:

Secondary Alternator Cover Part No. EC-CBR250RR-2016-1-GBR / Secondary Clutch Cover Part No. EC-CBR250RR-2016-2-GBR



SECONDARY ALTERNATOR COVER PART NO. EC-CBR250RR-2016-1-GBR

- 1. Remove fairing.
- Remove 4 existing bolts from the stock Alternator cover, shown as position Bolt 1, 2, 3 & 4
- Place the Secondary Alternator Cover over the stock cover.
- Assemble 4 replacement bolts loosely in the correct position as shown.
- Tighten bolts to a Torque of 10Nm as per Manufacturer's recommendations. DO NOT OVERTIGHTEN.
- Replace fairing.







SECONDARY CLUTCH COVER PART NO. EC-CBR250RR-2016-2-GBR

- 1. Remove fairing.
- Remove 4 existing bolts from the stock Clutch cover, shown as bolt position 1, 2, 3 & 4.
- Place the Secondary Clutch Cover over the stock cover.
- Loosely assemble 4 replacement bolts supplied.
- Tighten bolts to a Torque of 10Nm as per Manufacturer's recommendations.
 DO NOT OVERTIGHTEN.
- 6. Replace fairing.







SET: EC-CBR250RR-2016-SET-GBR: EC-CBR250RR-2016-1-GBR / EC-CBR250RR-2016-2-GBR



FITTING INSTRUCTIONS TO BE FITTED BY A QUALIFIED TECHNICIAN



PADDOCK STAND / BOBBIN SET PART NO. BA12-8-GBR-SET

- 1 Assemble M8 x 40mm Bolt through the moulded bobbin.
- 2 Tighten bolts to swing arm boss, 8 Nm. DO NOT OVERTIGHTEN





1 x Moulded Paddock Stand / Bobbin

LOWER CHAIN GUARD PART NO. CGA10-GBR

- 1 Assemble 2 bolts and washers through the lower chain guard into the Black Anodised aluminium mounting block CGA10-2.
- 2 Position the assembly underneath the swing arm, closing the gap to the rear sprocket.
 Note: There should be a 5mm minimum gap from the bike chain to the lower chain guard.
- 3 Mark off the chosen hole positions.
- 4 Drill & Tap the marked holes , M6 (Drill 5mm Dia. for tapping)
- 5 Disassemble the Black Anodised block from the assembly, and mount the block to the underside of the swing arm using the remaining 2 bolts and washers.
- 6 Re-assemble the lower chain guard to the fixed bracket.



2 x Bolts & Washers M6x20 - 10Nm

