

THIS SHEET INCLUDES FITTING INSTRUCTIONS FOR THE FOLLOWING PARTS:

Secondary Alternator Cover Part No. EC-RSV4-2010-1-GBR / Secondary Clutch Cover Part No. EC-RSV4-2010-2-GBR /
Bullet Frame Race Slider Set - RACE - Part No. FS-RSV4-2010-R / Paddock Stand / Bobbin Set Part No. BA12-6-RSV4-GBR-SET /
Brake & Clutch Lever Guards Part Nos. BLG-M18-S15-A160-GBR & CLG-M18-S15-A160-GBR





Please note: For the 2017 model onwards, the **alternator** and **clutch** have a standard dust cover fitted to brackets.
The fixing studs and brackets will need to be removed before fitting the GBRacing alternator / clutch cover. (For clutch: **See Fig. 2 below**).

SECONDARY ALTERNATOR COVER
PART NO. EC-RSV4-2010-1-GBR

Fits 2010-2020 models only. Alternator cover does not fit 2021 model

- 1 Remove 4 existing bolts from the stock Alternator cover, shown as position Bolt 1, 2 3 & 4. Retain stock bolt washers.
- 2 Place the Secondary Alternator Cover over the stock cover.
- 3 Assemble 4 replacement bolts, reuse stock bolt washers, loosely in the correct position as shown. *The retained stock washers are fitted between the engine casing and the GBRacing cover - See Fig. 1.*



SECONDARY CLUTCH COVER
PART NO. EC-RSV4-2010-2-GBR

See note at top of page re dust cover

- 1 Remove 3 existing bolts from the stock Clutch cover, shown as position Bolt 1, 2 & 3. Retain stock bolt washers.
- 2 Place the Secondary Clutch Cover over the stock cover.
- 3 Assemble 3 replacement bolts, reuse stock bolt washers loosely in the correct position as shown. *The retained stock washers are fitted between the engine casing and the GBRacing cover - See Fig. 1.*
- 4 Tighten bolts to a Torque of 12Nm as per Manufacturer's recommendations. **DO NOT OVERTIGHTEN.**





Fig 2



BULLET FRAME SLIDER - LEFT HAND SIDE - RACE
PART NO. FS-RSV4-2010-LHS-R

- 1 Remove upper engine mounting bolt, located through the fairing opening.
- 2 Assemble bolt through the aluminium bush into correct position.
- 3 Tighten to 25NM torque.
- 4 Slide bullet moulding onto aluminium bush.
- 5 Screw M6 bolt into front of bullet moulding hand tight.



BULLET FRAME SLIDER - RIGHT HAND SIDE - RACE
PART NO. FS-RSV4-2010-RHS-R

- 1 Remove upper engine mounting bolt, located through the fairing opening.
- 2 Assemble bolt through the aluminium bush into correct position.
- 3 Tighten to 25NM torque.
- 4 Slide bullet moulding onto aluminium bush.
- 5 Screw M6 bolt into front of bullet moulding hand tight.



PADDOCK STAND / BOBBIN SET – PART NO. BA12-6-RSV4-GBR-SET

- 1 Assemble M6 x 40mm Bolt & M6 Washer for the right hand side through the moulded bobbin.
- 2 Assemble M6 x 50mm Bolt & M6 washer for the left hand side through the moulded bobbin. This is to allow for the refitment of the original lower chainguard.
- 3 Tighten bolts to swing arm boss, 8 N/m.

1 x M6 40/50 Bolt

Washer



1 x Moulded Paddock Stand / Bobbin



SETS & BUNDLES

SET: EC-RSV4-2010-SET-GBR: EC-RSV4-2010-1-GBR / EC-RSV4-2010-2-GBR (2010-2020 models only)

BUNDLE: CP-RSV4-2010-CS-GBR: EC-RSV4-2010-1-GBR / EC-RSV4-2010-2-GBR / BA12-6-RSV4-GBR-SET (2010-2020 models only)

M18 THREADED BRAKE LEVER GUARD, 15mm SPACER BAR END, 160mm
PART NO. BLG-M18-S15-A160-GBR

- 1 Remove existing bar end and replace with supplied assembly as in Fig 1 below.
 - 2 Tighten bolt until the lever protector is tight and does not move up or down under normal pressure. Torque the M6 bolt to 12Nm.
 - 3 Do not ride if you are unsure if it is tight enough and always get a trained technician to confirm.
- Please note: We recommend to use a medium thread lock (not supplied) for correct operation.*



Fig. 1: ASSEMBLY



M18 THREADED CLUTCH LEVER GUARD, 15mm SPACER BAR END, 160mm
PART NO. CLG-M18-S15-A160-GBR

- 1 Remove existing bar end and replace with supplied assembly as in Fig 1.
 - 2 Tighten bolt until the lever protector is tight and does not move up or down under normal pressure. Torque the M6 bolt to 12Nm.
 - 3 Do not ride if you are unsure if it is tight enough and always get a trained technician to confirm.
- Please note: We recommend to use a medium thread lock (not supplied) for correct operation.*

Fig. 1: ASSEMBLY

