

FITTING INSTRUCTIONS

TO BE FITTED BY A QUALIFIED TECHNICIAN

PADDOCK STAND BOBBINS

THIS SHEET INCLUDES FITTING INSTRUCTIONS FOR THE FOLLOWING PARTS:

Part Nos. BA12M-6-GBR-SET / BA12M-8-GBR-SET / BA12M-10-GBR-SET / BA12M-10-1-5-GBR-SET / BA12M-6-RSV4-GBR-SET

PADDOCK STAND / BOBBIN SET - PART NO. BA12M-6-GBR-SET

- 1 Assemble M6 x 40mm 1mm pitch Bolt & M6 Washer through the moulded bobbin.
- 2 Tighten bolts to swing arm boss, 8 Nm.

1 x M6 x 40A2 Bolt Washer



1 x Moulded Paddock Stand / Bobbin



PADDOCK STAND / BOBBIN SET - PART NO. BA12M-8-GBR-SET

- 1 Assemble M8 x 40mm 1.25 mm pitch Bolt through the moulded bobbin.
- 2 Tighten bolts to swing arm boss, 8 Nm.
DO NOT OVERTIGHTEN



1 x M8 x 40A2 Bolt




1 x Moulded Paddock Stand / Bobbin



PADDOCK STAND / BOBBIN SET - PART NO. BA12M-10-GBR-SET

- 1 Assemble the M10 x 40mm 1.25 mm pitch Bolt through the moulded bobbin.
- 2 Tighten bolts to the swing arm boss, 8 N/m.
DO NOT OVERTIGHTEN.



1 x M10 x 1.25 x 40A2 Bolt



1 x Moulded Paddock Stand / Bobbin



PADDOCK STAND / BOBBIN SET - PART NO. BA12M-10-1-5-GBR-SET

- 1 Assemble the M10 x 40mm 1.5 mm pitch Bolt through the moulded bobbin.
- 2 Tighten bolts to the swing arm boss, 8 N/m. DO NOT OVERTIGHTEN.



1 x M10 x 40A2 Bolt



1 x Moulded Paddock Stand / Bobbin



PADDOCK STAND / BOBBIN SET - PART NO. BA12M-6-RSV4-GBR-SET

- 1 Assemble M6 x 40mm 1 mm pitch Bolt & M6 Washer for the right hand side through the moulded bobbin.
- 2 Assemble M6 x 50mm Bolt & M6 washer for the left hand side through the moulded bobbin.
This is to allow for the refitment of the original lower chainguard.
- 3 Tighten bolts to swing arm boss, 8 N/m.

1 x M6 x 40A2 Bolt Washer



1 x Moulded Paddock Stand / Bobbin

