



THIS SHEET INCLUDES FITTING INSTRUCTIONS FOR THE FOLLOWING PARTS:

Secondary Alternator Cover Part No. EC-ZX10-2011-1-GBR / Secondary Clutch Cover Part No. EC-ZX10-2011-2-GBR / Secondary Pulse Cover Part No. EC-ZX10-2011-3-GBR / Bullet Frame Race Slider Set - STREET - Part No. FS-ZX10-2011-S / Bullet Frame Race Slider Set - RACE - Part No. FS-ZX10-2011-R



SECONDARY ALTERNATOR COVER
PART NO. EC-ZX10-2011-1-GBR

1. Remove Lower Fairing panel.
2. Remove 4 existing bolts from the stock Alternator cover, shown as position Bolt 1, 2, 3 & 4.
3. Place the Secondary Alternator Cover over the stock cover.
4. Assemble 4 replacement bolts loosely in the correct position as shown.
5. Tighten bolts to a Torque of 11Nm as per manufacturer's recommendations.
DO NOT OVERTIGHTEN.
6. Re-Fit Lower Fairing Panel.



SECONDARY CLUTCH COVER
PART NO. EC-ZX10-2011-2-GBR



1. Remove Lower Fairing panel.
2. Remove 3 existing bolts from the Clutch cover, shown as position Bolt 1, 2 & 3.
3. Place the Secondary Clutch Cover over the stock cover.
4. Assemble 3 replacement bolts loosely in the correct position as shown.
5. Tighten bolts to a Torque of 11Nm as per manufacturer's recommendations.
DO NOT OVERTIGHTEN.
6. Re-Fit Lower Fairing panel.



SECONDARY PULSE COVER
PART NO. EC-ZX10-2011-3-GBR

1. Remove 3 existing bolts from the Pulse cover, shown as position Bolt 1, 2 & 3.
2. Place the Secondary Pulse Cover over the stock cover. Assemble 3 replacement bolts loosely in the correct position as shown.
3. Tighten bolts to a Torque of 11Nm as per manufacturer's recommendations.

DO NOT OVERTIGHTEN.




BULLET FRAME SLIDER - LEFT HAND SIDE - STREET
PART NO. FS-ZX10-2011-LHS-S

- 1 Remove upper engine mounting bolt, located through the fairing opening.
- 2 Assemble bolt through the aluminium bush into correct position.
- 3 Tighten to 40NM torque.
- 4 Slide bullet moulding onto aluminium bush.
- 5 Screw M6 bolt into front of bullet moulding hand tight.



BULLET FRAME SLIDER - RIGHT HAND SIDE - STREET
PART NO. FS-ZX10-2011-RHS-S

- 1 Remove upper engine mounting bolt, located through the fairing opening.
- 2 Assemble bolt through the aluminium bush into correct position.
- 3 Tighten to 40NM torque.
- 4 Slide bullet moulding onto aluminium bush.
- 5 Screw M6 bolt into front of bullet moulding hand tight.



BULLET FRAME SLIDER - LEFT HAND SIDE - RACE
PART NO. FS-ZX10-2011-LHS-R

- 1 Remove upper engine mounting bolt, located through the fairing opening.
- 2 Assemble bolt through the aluminium bush into correct position.
- 3 Tighten to 40NM torque.
- 4 Slide bullet moulding onto aluminium bush.
- 5 Screw M6 bolt into front of bullet moulding hand tight.



BULLET FRAME SLIDER - RIGHT HAND SIDE - RACE
PART NO. FS-ZX10-2011-RHS-R

- 1 Remove upper engine mounting bolt, located through the fairing opening.
- 2 Assemble bolt through the aluminium bush into correct position.
- 3 Tighten to 40NM torque.
- 4 Slide bullet moulding onto aluminium bush.
- 5 Screw M6 bolt into front of bullet moulding hand tight.

